




Plip ON/OFF switch to ON position




Wait for temperature gauge to read 150°F/66°C




Prescrap wares and load into rack




5 Load rack into dishwasher



Close door, press and hold START button for 1 second and green in-cycle light will indicate the cycle has begun



Final rinse temperature should be a minimum of 180°F/82°C during final rinse.



Wash cycle is extended if incoming water temperature is below requirments.



The cycle is completed when the green light is no longer lit.

You may now remove your clean wares.

Exercise caution handling wares as they may be hot.