
Operation

Refer to the <u>Theory of Operation</u> and <u>Waste Handling Precautions</u> beginning on page 1 of this manual prior to operating the waste handling system.

- 1. Turn on main power supply and water supply.
- 2. Make sure all drain valves are closed.
- 3. Inspect the interior of the pulper tank for metal or other debris.
- 4. Inspect the interior of the water extractor and make sure it is clean.
- 5. Check the (optional) deodorizer chemical container and replenish as necessary.
- 6. Open the water extractor discharge chute and make sure that the top of the water extractor and especially the space directly under the compression cone is clear of any obstructions.
- 7. Fully close the discharge chute and place a refuse container under the chute.
- 8. Make sure the safety switch on the water extractor and the pulper are in place and secure.
- 9. Make sure all access doors, feed hoods, curtains and covers are in place and secure.
- 10. Make sure all personnel are standing away from the waste handling system.
- 11. Turn the Main Circuit Breaker Switch on the remote control cabinet to the ON position. The Power On light illuminates and the pulper fills with water.
- 12. Push the green Start push button on the Water Extractor.
 - A. The pulper drive motor and the water extractor drive motor will run.
 - B. The optional recirculating pump motor (if equipped) will run.
- 13. If equipped, push the (optional) deodorizer switch ON. The switch is located on the remote control cabinet.
- 14. Feed a combination of food waste, paper waste, and cardboard into the pulper. Cardboard boxes must be reduced in size before loading.
- 15. Push the red Stop push button on the water extractor to Stop the system.
- 16. In case of an emergency, the system also can be turned off by rotating the Main Circuit Breaker Switch on the remote control cabinet counter-clockwise (CCW) to the OFF position.



Main Circuit Breaker Switch in the OFF position







Start/Stop Station OFF.

Start/Stop Station ON.

